


PRFL24/44/64 FLANGED FIXTURE INSTALLATION











- INSTALLED. DO NOT MIX LENS OR TRAYS.
- 2. MOUNT FIXTURE TO 1/4-20 ROD (BY OTHERS) AT MOUNTING LOCATIONS. REFER TO JOB DRAWINGS FOR MOUNTING LOCATIONS. 1/4-20 ROD MUST BE SECURELY FASTENED TO STRUCTURE.
- 3. JOIN FIXTURES WITH SUPPLIED HARDWARE. CONNECT WIRE HARNESSES. CONTINUE INSTALLING AND JOINING FIXTURES UNTIL ROW IS COMPLETE. MAKE SURE ALIGNMENT TABS ARE SEATED PROPERLY WHILE TIGHTENING HARDWARE.
- 4. DETERMINE POWER FEED LOCATION, REMOVE ACCESS PLATE, LED TRAY AND LENS FROM FIXTURE TO BE FED.

- APPROPRIATE STRAIN RELIEF TO SECURE CORD IN FIXTURE AS REQUIRED BY LOCAL ELECTRICAL CODES. CUT END FROM HARNESS AND CONNECT POWER FEED CONDUCTORS TO APPROPRIATE WIRES OF WIRE HARNESS. STANDARD WIRING DIAGRAM SHOWN, REFER TO JOB DRAWINGS FOR JOB SPECIFIC WIRING
- 6. REINSTALL ACCESS PLATE, LED TRAY AND LENS AFTER ALL WIRING CONNECTIONS ARE MADE. RE-INSTALL LED TRAYS AND LENSES IN ALL FIXTURES.
- 7. AFTER CEILING IS INSTALLED, SECURE TRIM TO CEILING USING APPROPRIATE SCREWS. PLASTER/MUD OVER TRIM TO FIXTURE EDGE. DO NOT PLASTER/MUD OVER FIXTURE LENS.



MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN. DISCONNECT POWER DURING INSTALLATION/SERVICING, ROW CONFIGURATION IS JOB SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS, STANDARD OPTIONS/SIZES SHOWN, OTHER OPTIONS AVAILABLE WITH SIMILAIR INSTALLATION. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. IMPORTANT: THE NATIONAL ELECTRIC CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX. DAY-O-LITE IS NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS, DAY-O-LITE RESERVES THE RIGHT TO MAKE ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE, THIS PRINT IS THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE.

MODEL NO.:
MODEL NO.: PRFL24/44/64-F

CONTACT INFORMATION:

126 Chestnut Street, Warwick, RI 02888 Tel. (401) 467-8232 | Fax. (401) 941-2960 E-mail: sales@davolite.com WWW: http://www.dayolite.com

Lighting Without Limits

PAGE:

SHEET 1 OF 2

PART NUMBER: 970024A0 ISSUED ON:

10/15/19

PRFL24/44/64 FLANGED FIXTURE INSTALLATION





ACCESS PLATE

LED TRAY

LENS

RISK OF ELECTRICAL SHOCK. **DISCONNECT POWER** BEFORE INSTALLATION OR SERVICING.





- 1. REMOVE LENS AND LED TRAY FROM FIXTURE TO BE INSTALLED. DO NOT MIX LENS OR TRAYS.
- 2. MOUNT FIXTURE TO 1/4-20 ROD (BY OTHERS) AT MOUNTING LOCATIONS. REFER TO JOB DRAWINGS FOR MOUNTING LOCATIONS. 1/4-20 ROD MUST BE SECURELY FASTENED TO STRUCTURE.
- 3. JOIN FIXTURES WITH SUPPLIED HARDWARE. CONNECT WIRE HARNESSES. CONTINUE INSTALLING AND JOINING FIXTURES UNTIL ROW IS COMPLETE. MAKE SURE ALIGNMENT TABS ARE SEATED PROPERLY WHILE TIGHTENING HARDWARE.

4. DETERMINE POWER FEED LOCATION. REMOVE ACCESS PLATE, LED TRAY AND LENS FROM FIXTURE TO BE FED.

5. FEED POWER FEED CORD THROUGH ACCESS PLATE. USE APPROPRIATE STRAIN RELIEF TO SECURE CORD IN FIXTURE AS REQUIRED BY LOCAL ELECTRICAL CODES. CUT END FROM HARNESS AND CONNECT POWER FEED CONDUCTORS TO APPROPRIATE WIRES OF WIRE HARNESS. STANDARD WIRING DIAGRAM SHOWN, REFER TO JOB DRAWINGS FOR JOB SPECIFIC WIRING

6. REINSTALL ACCESS PLATE, LED TRAY AND LENS AFTER ALL WIRING CONNECTIONS ARE MADE. RE-INSTALL LED TRAYS AND LENSES IN ALL FIXTURES.


7. AFTER CEILING IS INSTALLED, SECURE TRIM TO CEILING USING APPROPRIATE SCREWS. PLASTER/MUD OVER TRIM TO FIXTURE EDGE. DO NOT PLASTER/MUD OVER FIXTURE LENS.

MUST INSTALL PRIOR TO


DO NOT PLASTER/MUD

OVER FIXTURE LENS

CEILING.



ACCESS PLATE POWER FEED CONDUCTORS LED TRAY **LENS** WIRE HARNESS (CUT END OFF FOR CONNECTION TO POWER FEED)



MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN, DISCONNECT POWER DURING INSTALLATION/SERVICING, ROW CONFIGURATION IS JOB SPECIFIC, CONSULT SHOP DRAWINGS BEFORE CONSTRUCTING ROWS, STANDARD OPTIONS/SIZES SHOWN, OTHER OPTIONS AVAILABLE WITH SIMILAIR INSTALLATION. BE SURE TO UNDERSTAND ALL PROCEDURES PRIOR TO INSTALLATION. IMPORTANT: THE NATIONAL ELECTRIC CODE REQUIRES THAT ANY FIXTURE IN EXCESS OF 50 POUNDS MUST BE INDEPENDENTLY SUPPORTED OF THE OUTLET BOX, DAY-O-LITE IS NOT RESPONSIBLE FOR INADEQUATE REINFORCEMENT OF STRUCTURAL SUPPORT SYSTEMS, DAY-O-LITE RESERVES THE RIGHT TO MAKE ANY MECHANICAL OR MATERIAL CHANGES TO THE FIXTURES WHICH DO NOT AFFECT THE APPEARANCE OR PERFORMANCE. THIS PRINT IS THE PROPERTY OF DAY-O-LITE AND THE INFORMATION IT CONTAINS MAY NOT BE USED WITHOUT WRITTEN CONSENT OF DAY-O-LITE.

MODEL NO.: PRFL24/44/64-F----

SHEET 2 OF 2

ISSUED ON: 10/15/19

PART NUMBER: 970024A0

CONTACT INFORMATION:

126 Chestnut Street, Warwick, RI 02888 Tel. (401) 467-8232 Fax. (401) 941-2960 E-mail: sales@dayolite.com WWW: http://www.dayolite.com

